

Disassembling 6013

1. Loosen and remove coil nut with a 14mm ring spanner.
2. Lift off Cover from base of core tube to reveal 4 x screws.
3. Remove 4 x body screws using a T20 Tork bit.
4. Carefully pull core tube from body ensuring the plunger and spring are not lost.



Assembling 6013

5. Fit spring into hole in the back of the plunger.
6. Carefully insert plunger and spring into core tube.
7. Ensuring O-ring is correctly fitted in the base of the core tube, fit core tube to body using 4 x screws.
8. Place cover over base of core tube to cover screws.
9. Fit coil over core tube.
10. Tighten with coil nut using 14mm ring spanner

